

CONTI SWAGING DIAMETERS

This chart is intended as a guide only. Dimensions in mm.

Assemblies should be verified with the "Tail Crush Method" - Refer to the "Crimping FC Tails on Other Manufacturers Hoses" document (also available on our website)

FC Ferrule Code	Code on Ferrule	Use with what FC tails?	Hose Bore		-02	-03	-04	-05	-06	-08	-10	-12	-16	-20	-24	-32		
			Hose Type	dash	inch	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm
C-STO <i>(1-piece tails)</i>	SG-****	C-STO <i>(1-piece tails)</i>	FC Code				C-STO-04	C-STO-05	C-STO-06	C-STO-08	C-STO-10	C-STO-12	C-STO-16	C-STO-20				
			ContiTech R15 <i>(XCPS Hose)</i>					26.6	29.5	33.3	36.4	44.8	56.3					
SN1/2	03310-	STB	FC Code				SN1/2-04		SN1/2-06	SN1/2-08		SN1/2-12	SN1/2-16					
			ContiTech R2AT <i>(SR2SN Hose)</i>					24.4		32.4								
			ContiTech R2AT High Temp <i>(DR2SN Hose)</i>			18.8		21.8	-		32.1	40.3						
			<i>(Insertion Depth)</i>			24.8		26.0	27.5		35.0	42.5						